



## DIRECTIONS FOR USE

1. Carefully clean and dry the areas you intend to attach the film. The cleaner, drier and warmer these surfaces are when the film is first applied, the better the film will adhere and the more often it can be removed and reattached.
2. Peel back the free edge of the film and unroll a few inches.
3. Press the free edge to the vehicle surface.

**NOTE:** Do not use your bare hands to press the film down. Sharp edges can poke through the plastic and cut your skin. Always use a towel or leather gloves. Stretch the film slightly as you unroll it across the area to be covered.

**NOTE:** For large areas make several horizontal passes starting from across the bottom. With each pass overlap the previous one by a few inches. Then press the lapped areas together to make a seal. This creates a shingling effect that directs the water to the outside.

4. Finish by pressing the film against the vehicle with this product covering glass areas. Store Crash Wrap film in its original shipping carton.

**CAUTION:** DO NOT attempt to drive a vehicle with this product covering glass areas. Although it is transparent, it will distort and obscure your vision.

**CAUTION:** Haldon Company has tested this product in many different applications and concludes that it will perform satisfactorily when used as specified. Due to the wide variety of paints, solvents, weather conditions and customer uses, we recommend that you test our product under your particular conditions to determine its fitness for your needs.

For more information or advice using this product please call **ECP at 1-888-327-8463**